

Exam Code: 920-234

Exam Name: Nortel VPN Router Rls.7.0 Configuration &
Management (NCSS)

Vendor: Nortel

Version: DEMO

Part: A

1: A customer has a VPN Router 1750 with VPN tunneling capabilities. They want to enable subscribers to have user tunnel connections to the router. Which parameter must be configured to implement user tunnels on a VPN Router?

- A. a user group
- B. LDAP group settings
- C. password group settings
- D. an IP address assignment
- E. tunneling protocols settings

Correct Answers: D

2: An engineer wants to configure a firewall policy on the VPN router, and wants to change the system-wide rules that are applied and processed first by the firewall.

Which Stateful Firewall rules need to be modified?

- A. Implied Rules
- B. Default Rules
- C. Override Rules
- D. Interface-specific Rules.

Correct Answers: C

3: Which three VPN Router models support the "SSL VPN Module 1000" hardware option card? (Choose three.)

- A. VPN Router 1050
- B. VPN Router 1100
- C. VPN Router 1750
- D. VPN Router 2750
- E. VPN Router 5000

Correct Answers: C D E

4: A customer would like to use a VPN Router 1750 for SSL VPN and offload encryption onto multiple hardware accelerator cards.

Which statement is true?

- A. The 1750 chassis does not support the SSL VPN module or the hardware accelerator card.
- B. SSL VPN module and hardware accelerator cards can not be used in the same 1750 chassis.
- C. The 1750 chassis does support the SSL VPN module but only a single hardware accelerator card.
- D. The 1750 chassis does not support the SSL VPN module but multiple hardware accelerator cards could be installed.

Correct Answers: C

5: A customer has just purchased a VPN Router 1750. They want to know how much RAM it has "out-of-the-box" and if it can be upgraded.

Which statement is true?

- A.The VPN Router 1750 chassis comes with 256MB installed and is not upgradeable.
- B.The VPN Router 1750 chassis comes with 128MB of RAM installed and is upgradeable to 512MB.
- C.The VPN Router 1750 chassis comes with 256MB of RAM installed and is upgradeable to 512MB.
- D.The VPN Router 1750 chassis comes with 128MB of RAM installed and is upgradeable to 256MB.

Correct Answers: D

6: A customer has just purchased a VPN Router. They want to know which License Keys are available and what functions each individual key enables.

Which statement is true?

- A.The Advanced Routing key enables RIP, OSPF and VRRP functions.
- B.The Premium Routing key activates OSPF, VRRP, DLSw and BGP routing functions.
- C.The BGP Routing key enables Border Gateway Protocol routing and Data Link Switching capabilities.
- D.The VPN Router Stateful Firewall key enables stateful firewall capabilities but disables the standard VPN Router firewall functions.

Correct Answers: B

7: On a VPN Router Rls. 7.0 system, on which two interface types can the routing protocols RIP, OSPF and VRRP be enabled? (Choose two.)

- A.Single HSSI
- B.Single or Dual V.35
- C.10/100 Ethernet port, System Board
- D.10/100 Ethernet port, Expansion Module

Correct Answers: C D

8: Which three QoS features are available on the VPN Router? (Choose three.)

- A.CLIP
- B.DiffServ
- C.Demand Services
- D.Forwarding Priority
- E.Resource Reservation Protocol

Correct Answers: B D E

9: Which three statements are true regarding IPsec Mobility? (Choose three.)

- A.VPN tunnel connections survive lost packets.
- B.IPsec Mobility is activated with the Advance Routing license key.
- C.For IPsec Mobility to work, any VPN Client version can be running.
- D.NAT Traversal and IPsec Fail-over will not interoperate with IPsec Mobility.
- E.IPsec Mobility is provisioned at the VPN Router, and the settings are pushed down from the server.

Correct Answers: A B E

10: When configuring the VPN Router 1750 system, how are the management IP address and subnet mask initially configured?

- A.The management IP address and subnet mask are configured by using the serial interface.
- B.The management IP address and subnet mask will be automatically provided by a DHCP server.
- C.When powered up, the VPN Router will initially be configured with a default management IP address and subnet mask.
- D.Having the management IP address and subnet mask configured is not initially required and can

ERROR: rangecheck
OFFENDING COMMAND: xshow

STACK:

```
[44 39 22 39 44 44 29 24 44 44 29 39 43 22 29 29 44 67 22 39 22 63 39 44  
 22 44 29 44 63 34 39 2922 39 24 22 39 44 43 24 25 67 39 0 ]  
(be configured from a web browser at anytime.)
```